

COPYRIGHTED

Reproduction of programs
in equipment is expressly
forbidden without written
consent of ZeeCraft Co.,
LCC

Revised August, 2025



221 Norris Dr., Suite 4 Rochester, NY 14610
PHONE: 1-800-662-7475
EMAIL: zeeecraft@zeeecraft.com
www.zeeecraft.com

WIRED CHALLENGER I

Please read through **ALL** instructions prior to setup.

Congratulations on the purchase of your **Challenger I Buzzer System!** This system utilizes state-of-the art surface mount microprocessor circuitry and will provide years of trouble-free service. If a problem should develop, we suggest that you contact us immediately. If the problem cannot be solved in the field, instructions will be provided for returning the unit to ZeeCraft for proper servicing. When setting up the system, make sure there is an electrical outlet nearby.

The operation of this equipment is quite simple. We offer the following instructions to ensure optimal use. First, plug all buzzers into the ports located on the back of the control box. The plugs are easily inserted by pushing the phone clips into the ports until the tab on each clip 'clicks' into place. For removal, simply depress the tab and pull out. It should also be noted that extreme care should be exercised so that no foreign objects are inserted in the connection ports, which could result in damage to the unit. All buzzers of one color should be plugged into one side, with the second color on the other side, although mixing colors will not affect operation. (Standard colors are red and white but many other colors are available.) The cords provided are 14' to allow for proper seating and spacing.

Plug the power supply into any standard outlet (surge protector recommended), then insert the jack of the power supply into the back of the control box. At this point, the equipment will automatically proceed through a programmed test. At the completion of the test, a tone will sound, which indicates that you are now ready to use the equipment.

First, press the **Reset** button on top of the control box. Then, activate each buzzer by pressing its button; the control box will beep and that buzzer will light up. Following a ring-in, all buzzers will be locked out from activation until the system is reset. Press the Reset button to clear a buzzer after a ring-in. Repeat until all buzzers have been tested. The system is now ready for play. A few practice rounds will help you master the features described herein.

EXPLANATION OF THE DIP SWITCHES

DIP switches must be set prior to play. Once the control box is plugged in, system settings **CANNOT** be altered. Please read instructions and identify desired settings before operating the system. When altering DIP switch settings, unplug the control box and adjust switches to desired positions.

Switch 1: Volume High/Volume Low In the **DOWN** position, volume is low; in the **UP** position, volume is high.

Switch 2: Freeze Clock / Off Challenger I control boxes do not include a countdown clock. DIP switch 2 only applies to Challenger II and Challenger III systems, and does not affect the functionality of the control box in either position.

Switch 3: Distinguish 2 Teams / Distinguish Up to 4 Teams Switch 3 in the **DOWN** position will allow up to four teams to play at once, with 4 buzzers able to participate on each team. The **UP** position will allow for two teams to play, with a maximum of 8 players on either team. For an 8-port control box, only two teams can play at once. In either position, teams are distinguished by different tones when buzzers activate. The control box will beep once for team 1, twice for team 2, three times for team 3, four for team 4, with the pitch of the beep raising from team 1 to team 4 successively.

Switch 4: Identify 1st, 2nd Place / 1st Place Only Switch 4 in the **DOWN** position will allow the system to identify only the 1st player to ring in, with the rest of the buzzers locked out. Switch 4 in the **UP** position will allow the system to identify both the 1st player and the 2nd player to ring in as long as the second player is from a different team. The 2nd buzzer to activate will have a flashing light. Pressing the **Reset** button once will clear the 1st place ring in and the 2nd place buzzer will display steady illumination. A second reset will clear the system. If a 1st and 2nd place ring in are recognized by the system, all buzzers will be locked out from activation.


Switch 5: Set Time / Run Time Challenger I control boxes do not include a countdown clock. For Challenger II and Challenger III systems, switch 5 allows for reprogramming timer settings for the countdown clock. Switch 5 **MUST** be in the **DOWN** position for the system to operate as a lock-out system. The buzzers will not be able to connect to the control box if switch 7 is in the **UP** position.

Switch 6: Stand Alone or Host Unit / Multi-Unit Setup Switch 6 in the **UP** position allows the control to operate as a Stand Alone unit or as a Host Unit for Multi-Unit Play. Switch 6 in the **DOWN** position will allow the control box to be used as a Remote unit for Multi-System play.

Note: Switch 6 **MUST** be in the **UP** position for the system to operate as a standard lock-out system.

Switch 7: Remote / Remote Used for Multi-System play. This special feature is not included in standard Challenger systems. See ‘Special Features’ section for details about Multi-System play or contact ZeeCraft for instructions in connecting Challenger control boxes for a multi-system setup.

Switch 8: 2 Digit System / 3 Digit System Challenger I control boxes do not include a countdown clock. DIP switch 8 only applies to Challenger II and Challenger III systems, and does not affect the functionality of the control box in either position.



TIPS FOR SAFETY, MAINTENANCE, AND TROUBLESHOOTING

1. Under normal circumstances your Challenger system will operate as soon as it is plugged into any standard wall outlet. Since this equipment utilizes microprocessor circuits, we recommended using a **surge protector** between the power supply and the wall outlet. By doing so, you will minimize the possibility of a circuit failure that can result from **voltage spikes**.
2. Replacement Power Supply specifications: INPUT: 100-120 VAC 50/60 Hz 0.4A
OUTPUT: +9V 2A
3. When storing your equipment, never wrap the wire of the buzzer around the buzzer itself. This will eventually cause the wire to break, resulting in its function ceasing. ZeeCraft recommends coiling the wire from the black case outward towards the clip, and then securing the wire with a wire-tie or velcro.
4. If a buzzer fails to operate, the clip on the end of its wire is a possible source of the problem. ZeeCraft recommends purchasing a repair kit for replacing broken clips. Replacement light bulbs can also be purchased from ZeeCraft (LED ShowTime buzzers excepted).
5. If none of the buzzers in the system are able to connect to the control box, the box is likely the source of the problem. If this happens, unplug the control box and check DIP switches 5 and 6. DIP switch 5 **MUST** be in the **DOWN** position, and switch 6 **MUST** be in the **UP** position for the Challenger system to operate as a standard lock-out system.
6. All ZeeCraft Products can be returned for repairs. After troubleshooting, if you continue to experience problems, contact ZeeCraft for guidance in beginning repair process. Repair forms are downloadable from our website at zeecraft.com.

WARRANTY

All ZeeCraft products carry a one year manufacturer's warranty from the date of shipment against defects in material and workmanship. During this period, such defects will be repaired, or the product will be replaced at ZeeCraft's discretion. The customer is responsible for sending defective products to ZeeCraft, and ZeeCraft will not charge the customer for repair services or shipping that are covered under warranty. It is the customer's responsibility to inform ZeeCraft of any warranty claim. This warranty does not cover damage caused by accident, misuse, or negligence.

The customer may purchase an extended warranty that covers ZeeCraft products for an additional three years beyond the end of the standard warranty period. Contact ZeeCraft for details.

IMPORTANT SAFEGUARDS

WARNING: To reduce the risk of fire or electrical shock, do not expose this appliance to rain or other moisture. Moisture can damage internal parts.

ANY QUESTIONS?

Please call ZeeCraft at
1-800-662-7475

CAUTION

RISK OF ELECTRIC SHOCK
DO NOT OPEN

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK,
DO NOT REMOVE COVER. NO USER SERVICEABLE PARTS INSIDE.
REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

Special Features

These features are only available on the 'Build a Buzzer' page on ZeeCraft's website and are **NOT** included in standard Challenger systems. These features can be retrofitted to existing Challenger systems in customer's possession. Contact ZeeCraft for details.

1. Volume Control

Audio Taper Volume Knob installed on the control box for adjusting volume range. Maximum volume does not exceed default 'High' setting for control boxes.

2. Line Level Output

The Box will include a 1/4" jack which will have line-level output for an audio mixer or room system. This allows the buzzer system's audio to be amplified for auditoriums/large rooms without needing a microphone. Audio cable not included.

3. Multi-System Play

The control box will have ports for connecting it to additional control boxes to expand the player pool. Up to three 16-player control boxes can be daisy-chained, with one acting as a 'host unit,' allowing a maximum of 48 players to participate at once. Wired and wireless control boxes can also be daisy-chained together. Includes one daisy-chain cable for multi-system play.

4. Remote Reset

The control box will include a plug-in port and a 14' cable with a HandGrip for resetting buzzers remotely. This will allow moderators to clear buzzers without needing the control box within an arm's reach. Alternate lengths and triggers are available. Contact ZeeCraft for pricing.

5. Multi-Player Team Hub Setup

The buzzer system will include a set of Team Hubs that each connect to one buzzer at a time in the system. Buzzer systems can include up to 16 buzzers, and each Hub includes ports for five players. At capacity, a single buzzer system will have 16 teams of 5 players active at once, totaling 80 participants for a quiz bowl event. Customer may specify what triggers they desire for Team Hubs, which do not need to be uniform across the entire system.

The Multi-Player Team Hub option includes a set of boxes that connect multiple buzzer inputs together. Similar in style to 'slap-box' options, this feature distinguishes between teams but not individuals. Systems can accept up to 16 inputs, and each multi-player hub can connect to multiple players. Individual triggers can include any of our available options and do not have to be the same style.

6. Bonus button

When pressed, this button will illuminate all of the buzzers for a single team in succession to indicate a "Bonus Round" of questions. When pressed additional times, the Bonus Button will cycle through each team in a buzzer system (which can include up to 4 teams) and illuminate them. Buzzers cannot activate while the system is in Bonus Mode, and the Reset button will clear Bonus Mode.